



## KynSHOT Selectable Damping Buffer RB5100 Adjustment Guide:

Instruction Manual 46021 Revision A



### 1. Where is the Adjustment Knob Located?

The adjustment knob on the RB5100 is located at the top of the buffer, where the cylinder threads into the stock adapter.



### 2. Which Way Can the Buffer Be Adjusted?

The adjustment knob can be turned clockwise or counterclockwise.



**3. RB5100 Adjustment Instructions:** There are three different setting options on the buffer, 0 (open), MD (Medium Damped), and HD (Heavy Damped). To select the damping, loosen the set screw on the side of the cylinder with the .050 hex key provided with the buffer.



4. Once set screw is loosened, use a flathead screwdriver to select the damping level by twisting the adjustment knob. (located at the top of the buffer)



5. With the damping selected, on the side of the cylinder where you loosened the set screw, take the .050 hex key again, and tighten the set screw locking the adjustment knob into place. Please note: You do not need to over tighten the set screw.